



## Feeder F-200

### A) Batteries installation

Open the case with a phillips screwdriver. Install the 4 C size batteries on the battery clip. The motor will start for 20 secondes and will stop.


### B) Programmation:

Press R key for reset the clock.

Example: If you reset the clock at 7:00 o'clock the feeder will be run everyday at 7:00 o'clock.


After that if you press the H key to set 12 the feeder will be run at 7:00 o'clock and 19:00 o'clock everyday.

By default the feeder is program to give 1 portion for each feed. But you can program from 1 to 3 portions per feed by pressing P key.



5 GALLONS container or more  
(not included)

Make a hole 1 1/2 inch in the middle of your container.



**Circuitronique Estrie Inc. 6291 Tellier, Quebec J1N 3A8**

**Phone: (819) 864-4637**

**email: [info@vigil.qc.ca](mailto:info@vigil.qc.ca)**

**Web site: [www.vigil.qc.ca](http://www.vigil.qc.ca)**